

Product Name: THE LYNCAR CURVED SHOWER ROD
Product #: 1280

The curved shower rod is designed to give you the feel of a larger tub – without the time and expense of actually installing a new one. They are designed to fit 5' standard or oval tubs. The rod curves 6" outward in the centre, creating much more open space.

In addition, the rod curves 3" inward at both corners which allows your shower curtain to stop water from escaping.

The rod is compatible with standard shower curtains – no special curtains are necessary.

There is a one year manufacturer's warranty.

MOUNTING INSTRUCTIONS:

FOR 60" STANDARD TUB:

Mount rod approximately 3" inside the point where a straight rod is normally mounted. The midpoint of the rod should extend several inches outside the rim of the tub.

FOR 60" OVAL TUB:

Depending on the tub model, the rod should be mounted between 6" and 8" from the centerline of the tub. The middle portion of the rod should curve to just outside the contour of your tub.

- 1 Remove existing shower rod and curtain.
- 2 Position the rods wall mounts onto your walls of the shower in the position that best fits your shower.(NOTE: Positioning over a stud in the wall when possible is the best place to provide the best mounting surface.)
- 3 Measure: Hold the rod up to the desired position, having one person at each end to check the height and location. Make sure the rod is level. With a pencil, lightly trace the top and bottom of wall plate and place rod off to the side.
- 4 Reposition the wall mounts back onto the traced outlines and mark the screw holes for each one.
- 5 Drill a small pilot hole into each screw hole that was marked in step 4.
- 6 If a stud is present, use the small wall mount screws for fastening the wall mounts to the wall in the traced position.
- 7 If no stud is present, and you are attaching the wall mount directly to drywall, screw the drywall anchors into the pilot holes drilled in step 5 until they are flush with the surface.
- 8 If no stud is present, and you are attaching the wall mount through tile into drywall, first drill a ¼" hole through the pilot holes and then insert the tile anchors until they are flush with the surface.
- 9 Use the small wall mount screws to then attach the wall mounts into the anchor holes.
- 10 Reposition the shower expander with the curtain and swivel ends installed back onto the wall mounts. Then secure with the large swivel bolts on the top and bottom.
- 11 Insert and tighten the set screws in order to hold the shower expander rod in