

Product Name: New Style Cartridge for WALTEC - Cold
Product #: 911

Read instructions carefully before installing.

Carefully compare the length and appearance of your stem.

1. Turn off water to faucet.
2. Remove faucet handle.
3. Remove old stem, replace with new.

NOTE: For faucets manufactured after 1990, remove lower "O" ring before installation.

OEM (Original Equipment Manufacturer) numbers, registered / non registered trademarks, faucet name, and manufacturer listed above are supplied and listed for your reference only. All LynCar items are precision made and tested to the highest standards, by qualified factories inspected and approved by LynCar.

Lisez attentivement les instructions avant de l'installer

Comparez soigneusement la longueur et l'apparence de votre tige.

1. Coupez l'arrivée d'eau au robinet.
2. Démontez la poignée du robinet.
3. Enlevez la tige usage et remplacez - la par une tige neuve.

NOTE: Pour les robinets fabriqués après 1990, enlevez le joint torique intérieur avant d'installer.

OEM (LES PIÈCES ORIGINALES DU FABRICANT= les numéros, les licences les noms des robinets ainsi que du fabricant le sont pour votre référence seulement. Toutes les pièces "LYNCAR" sont fabriquées avec précision et testées aux normes les plus élevées, vérifiées et inspectées avant d'être approuvée par "LYNCAR"